





CLEANING Ø50 MM


CLEANING BENDS & PIPES



CLBE/CLPI
CLBE-050 cleaning bend fits with CLPI-050 two piece cleaning pipe and floor nozzle FLNO and FLNZ.




CLPA & CLPC
CLPA-050 och CLPC-050 complete cleaning pipes that fit with floor nozzle FLNO and FLNZ.



CLPF
CLPF-050 complete aluminium cleaning pipe with floor nozzle.

NOZZLES - FLOOR



FLNO
FLNO-050 floor nozzle fits all cleaning pipes except CLPF.

With wheels and brush list as standard. There is optional rubber molding.

NOZZLES - TABLE

	CLBZ	CLBZ-050 brush 90° fits floor pipe or hose with STAD+MUHO.
	CLBR	CLBR-038-050 brush 45° fits hose with MUHO.
	PTNO	PTNO-050 crevice nozzle fits floor pipe or hose with STAD+MUHO.
	CLNO	CLNO-050 crevice nozzle fits hose with MUHO.
	PLNO	PLNO-050 pipe nozzle fits floor pipe or hose with STAD+MUHO.
	TFNO	TFNO-050 transverse nozzle fits hose with STAD+MUHO.
	STNO	PTNO-050 steel crevice nozzle fits floor pipe or hose with STAD+MUHO.
	CONO	CONO-050 conical nozzle fits floor pipe or hose with STAD+MUHO.

Note that most nozzles also fit with CLBE cleaning bend.

HOSR
Lajac's self-made ergonomic hose reel with black antistatic hose (AHNO).

Fits with CLBE bend and CLPI two-piece cleaning pipes as well as several countertop nozzles together with MUHO hose socket.

Also available in ATEX-rated version. Both models are supplied wall-mounted as standard, but can be ordered for ceiling mounting or mounted on HOSA arm.



HOSA
Extension arm for HOSR hose reel.

ADAPTERS/COUPLINGS

	STAD	STAD-050 metal adapter to connect hose with bench nozzles.
	MUHO	MUHO-050 antistatic hose socket between adapter STAD and hose.
	COKL	COKL flap valve with pull ring edge, transition piece to cleaning system.
	HOCO	HOCO hose coupling as connection between hose and PIDI.
	PIDI	PIDI-050 adapter to connect HOCO with all cleaning pipes.
		Example (fr. right): Flap valve COKL Hose coupling HOCO Hose ANHO Hose coupling HOCO Adapter PIDI