





Cleaning system Ø38mm


CLEANING BENDS & PIPES



CLBE/CLPI
CLBE-038 cleaning bend fits with CLPI-038 two piece cleaning pipe and floor nozzle FLNO and FLNZ, also with all table brushes and nozzles.




CLPA/CLPC
CLPA-038 and CLPC-038 complete cleaning pipes that fit with floor nozzle FLNO and FLNZ, also with all table brushes and nozzles.



CLPT
CLPT-038 aluminum telescopic cleaning pipe fits with FLNO and FLNZ floor nozzles, also with all table brushes and nozzles.

NOZZLES - FLOOR



FLNO
FLNO-038 floor nozzle fits all cleaning pipes

FLNZ
FLNZ-038 floor nozzle fits all cleaning pipes

With wheels and brush list as standard. There is optional rubber list.

NOZZLES - TABLE

	CLBZ	CLBZ-038 brush 45° fits floor pipe or hose with STAD+MUHO.
	PTNO	PTNO-038 crevice nozzle fits hose with MUHO.
	CLNO	CLNO-038-050 crevice nozzle fits hose Ø38 with STAD+MUHO.
	PLNO	PLNO-038 pipe nozzle fits floor pipe or hose with STAD+MUHO.
	CLBR	CLBR-038-050 brush 45° fits hose with MUHO.
	TFNO	TFNO-038 nozzle fits floor pipe or hose with STAD+MUHO.
	STNO	STNO-038 crevice steel nozzle fits floor pipe or hose with STAD+MUHO.
	CONO	CONO-038 conical nozzle fits floor pipe or hose with STAD+MUHO.
	PKBR	PKBR-038 cable brush fits with CLPT telescope pipe or STAD+MUHO.

Note that most nozzles also fit with CLBE cleaning bend.

HOSR
Lajac's self-made ergonomic hose reel with black antistatic hose (AHNO).

Fits with CLBE bend and CLPI two-piece cleaning pipes as well as several countertop nozzles together with MUHO hose socket.

Also available in ATEX-rated version. Both models are supplied wallmounted as standard, but can be ordered for ceiling mounting or mounted on HOSA arm.

HOSA
Extension arm for HOSR hose reel.

ADAPTERS/COUPLINGS

	STAD	STAD-038 metal adapter to connect hose with table nozzles.
	MUHO	MUHO-038 antistatic hose socket between adapter STAD and hose.
	Example: Hose AHNO Hose socket MUHO Adapter STAD Nozzle TFNO	
	KLVA	KLVA flap valve, conical, mounted inside the pipe.
	KLVP	KLVP flap valve, mounted on the pipe with PICO coupling
	COKL	COKL flap valve with pulling edge, transition piece to cleaning system.
	HOCO	HOCO hose coupling as connection between hose and PID1.
	PID1	PID1-038 adapter to connect HOCO with all cleaning pipes.
	Example: Flap valve COKL / KLVA / KLVP Hose coupling HOCO Hose AHNO Hose coupling HOCO Adapter PID1	